

2.5" Button Maker Guide

50 cents per button

1. Print or draw your design on paper. It must be 2.5" or less. We have free pre-cut designs.
2. Place the materials in this order into a slot labeled "SHELL DIE"
 - a. Shell at the bottom (curved side face up)
 - b. The design (face up)
 - c. Mylar (plastic film) at the top

MAKE SURE that you have only ONE piece of mylar or else the machine will jam.
3. Rotate the slots until your mylar sandwich is under the lever and press firmly.
4. Your mylar sandwich is now stuck under the lever. Pull the lever up.
5. Grab a back piece and place the squiggly side of it up into a slot labeled "BACK DIE"
6. Rotate the slots until your back piece is under the lever and press firmly.
7. Lift up the lever. Your button will be finished!
8. Use a magnet to grab the button.

Cutters Guide

Cutter #1 (Cuts any size)

1. Place the cutter on top of your design.
2. Change the size of the cut by loosening the gold screw and moving the blade underneath.
3. Moving the blade outward will make the circle larger, and moving the blade inward will make the circle smaller. Then tighten the screw.
4. Swivel the razor clockwise ↻ while pressing down to cut out a circle.

Cutter #2 (Only cuts 2.5" circles)

1. Slip your piece of paper into the top of the cutter. If the sheet is too wide then cut it thinner with scissors.
2. Line up your design with the circle.
3. Pull down the lever, and your design should pop out the circle.

Cutter #3 (Only cuts 1" circles)

1. Slip your paper into the cutter.
2. Line up your design with the circle.
3. Press down, and your design should cut.

1" Button/Magnet Maker

50 cents per piece

1. Print or draw your design on paper. It must be 1" or less. We have free pre-cut designs.
2. Place the materials in this order into a slot labeled "PICKUP"
 - a. Shell at the bottom (curved side face up)
 - b. The design (face up)
 - c. Mylar (plastic film) at the top

MAKE SURE that you have only ONE piece of mylar or else the machine will jam.
3. Rotate the slots until your mylar sandwich is under the lever and press firmly.
4. Your mylar sandwich is now stuck under the lever. Pull the lever up.
5. Grab a collet piece with the rounded side face down into the slot labeled "CRIMP"
6. Rotate the slots until your collet piece is under the lever and press firmly.
7. Lift up the lever. Insert either a magnet or pin into the back. Some force is necessary.